


BLUECARVE CNC

TouchBLUE

Tablet controller user manual

Getting started • Your first carve • Troubleshooting • Web page & Tools



Software version 1.3.3

Maltek Pty Ltd • Laverton North, Victoria, Australia

Contents

Read this first: safety	3
1 Getting started	4
1.1 What TouchBLUE does	4
1.2 Switching on and connecting	4
1.3 Finding your way around	4
1.4 Reading the machine state	5
1.5 A few words you will see	6
1.6 Homing the machine	6
1.7 Moving the cutter: Jog and Dial	7
1.8 Setting zero (where your job starts)	9
1.9 Spindle Mode and Laser Mode	11
1.10 Getting job files onto the machine	12
1.11 Previewing a file	13
1.12 Other settings	14
2 Your first carve	16
2.1 Overview: the workflow at a glance	16
2.2 Step 1: Power on and check the connection	16
2.3 Step 2: Home the machine	16
2.4 Step 3: Prepare the machine	17
2.5 Step 4: Choose the mode	17
2.6 Step 5: Choose and preview your file	17
2.7 Step 6: Move to the start point	17
2.8 Step 7: Set X and Y zero	17
2.9 Step 8: Set Z zero	17
2.10 Step 9: Final checks and Play	17
2.11 Step 10: While the machine carves	18
2.12 Step 11: Finish up	19
2.13 Doing the same with Simple Mode	19
3 Troubleshooting	20
3.1 First things to try	20
3.2 Connection problems	20
3.3 Common problems	20
3.4 Alarm messages	21
3.5 Error messages from the controller	23
3.6 Updating the software	23
3.7 Getting help	24
4 The web page: files, Tools and this manual	25
4.1 Surfacing the spoilboard	25
4.2 DXF → G-code	26
4.3 V-carve	28
4.4 Nest / array	29
4.5 Laser image	30
4.6 3D relief	30
4.7 Viewer & checker	31
4.8 Feeds & speeds	32
4.9 Saving projects and settings	33

Read this first: safety

A CNC machine can cause serious injury. The TouchBLUE tablet makes the machine easy to control, but it does not make it safe by itself. Please read and follow these points every time you use the machine.

- **Know where the machine's emergency stop (E-stop) is** and be able to reach it at all times while the machine is moving. The **STOP** button on the tablet ends a job and returns the machine to idle, but it is **not** an emergency stop and does not cut power.
- **Never leave a running machine unattended.**
- **Wear eye and hearing protection** and use dust extraction. Keep long hair, loose sleeves and jewellery well away from the cutter.
- **Clamp the material securely** before every job. Keep your hands clear of the cutter and gantry while the machine is powered.
- **Check the cutter, collet and spindle** before starting, and use only cutters rated for the spindle speed and the material.
- **Keep children and pets away** from the machine.
- If anything looks, sounds or smells wrong, **press the E-stop first**, then work out the cause.

About this manual

This manual covers TouchBLUE software version 1.3.3 on BlueCarve machines. It has four parts: **1. Getting started** (for first-time users), **2. Your first carve** (an overview of the whole workflow, then step by step), **3. Troubleshooting** and **4. The web page and Tools** (from a computer: sending files, surfacing, DXF → G-code with holding tabs, V-carve, nesting, laser image engraving, 3D relief, the G-code checker, feeds and speeds, and project files).

The screen pictures are illustrations that follow the tablet's layout. Machine names, file names and positions on your own tablet will differ.

1 Getting started

This section is for first-time users. It explains what TouchBLUE is, how to switch on and connect, what each screen does, and the handful of ideas you need before your first carve: homing, jogging and setting zero.

1.1 What TouchBLUE does

TouchBLUE is a touch-screen controller for your BlueCarve machine. The tablet talks to the machine's controller over WiFi. You use it to:

- move the cutter around (**jogging**) and send the machine to its reference position (**homing**);
- tell the machine where your job starts (**setting zero**), by hand or with a touch probe;
- choose, preview and run job files, and watch them carve;
- pause or stop a job, and adjust speeds while it runs;
- see alarms and errors explained in plain English.

1.2 Switching on and connecting

1. **Switch on the machine's own power** (the controller must have power, not just a USB connection).
2. **Power the tablet** with its USB-C power lead. The TouchBLUE logo appears, then the main screen.
3. **Wait for the connection.** The tablet joins the machine's WiFi network by itself. Look at the bar at the bottom of the screen: when the word at the left changes from a red **OFFLINE** to a green **IDLE**, you are connected.
4. If the bar shows **ALARM** in red, a message explains why. Tap **Clear Alarm**, or see section 3.

Preset connection details	
Machine WiFi network name	BLUECARVE
WiFi password	bluecarve
Controller address	192.168.0.1
Tablet web page (for sending files from a computer)	Normally 192.168.0.2. The exact address is shown on Settings > Machine .

Tip

You can send job files to the machine from your computer. Connect the computer to the **BLUECARVE** WiFi network too, then see section 1.10.

1.3 Finding your way around

The row of tabs along the top is the main menu. The bar along the bottom is always visible and shows the machine state and position.

Tab	What it is for
Status	The live view: state, positions, feed and spindle speed, input and fault lamps, messages and the Alarms button. Also holds the Spindle Mode / Laser Mode buttons. While a job runs it shows Pause and STOP .

Tab	What it is for
Control	Everything for moving the machine. It has five pages down the left: Actions (unlock, home, zero), Jog (step buttons), Dial (handwheel dials), Probe (touch-probe routines) and Overrides (change speed during a job).
Files	The files on the machine's SD card. Each file has a delete, preview (eye) and play button.
Preview	A drawing of the toolpath for the file you chose, with the job size in millimetres.
Macros	Buttons for saved sequences of commands.
Terminal	Advanced: type commands to the controller and read its replies. You do not need this for normal use.
Settings	Tablet settings: General, Backup, Power, Jog, Probe, WCS and Machine.




Figure 1: The Status tab

1.4 Reading the machine state

The machine state appears in large letters at the bottom left of every screen, and on the Status tab.

State	Colour	What it means
IDLE	Green	Ready. You can jog, set zero or start a job.

State	Colour	What it means
RUN	Cyan	A job is running.
JOG	Cyan	A jog move is in progress.
HOME	Blue	The homing cycle is running.
HOLD	Yellow	Paused. Press Resume to carry on.
ALARM	Red	The machine has stopped for a reason. A message explains it. Fix the cause, then clear the alarm. See section 3.4.
OFFLINE	Red	The tablet is not connected to the machine. See section 3.2.

The bottom bar also shows **WPos** (work position, relative to your job zero) and **MPos** (machine position), with the machine name and WiFi network at the right.

1.5 A few words you will see

Word	Meaning
Home / homing	Sending the machine to its limit switches so it knows where it is. Do this after every power-on, before jogging to your job.
Jog	Moving the machine by hand with the tablet, as opposed to running a job file.
Machine position (MPos)	Where the cutter is measured from the machine's home corner. It does not change when you set zero.
Work position (WPos)	Where the cutter is measured from your job's zero point . Job files use this.
Zero (work zero)	The point on your material that the job treats as X0 Y0 Z0. You set it each time you place new material.
G-code	The instructions in a job file (usually ending .nc or .gcode), produced by your CAM software.
Spindle / Laser mode	Which tool the machine is set to use. See section 1.9.
Feed rate	How fast the cutter moves through the material, in millimetres per minute.
Probe	A touch plate or block that lets the machine find the top (and sides) of your material automatically.
WCS	Work coordinate system – a stored zero point (G54 is the default). The tablet normally uses G54.

1.6 Homing the machine

Home the machine each time you switch it on. This lets the controller know where the cutter is, which it needs to keep the cutter inside the machine's travel limits.

1. Make sure the cutter is **clear of the material, clamps and anything on the bed**, and that the path to the home corner is clear.
2. Go to **Control > Actions**.
3. If the state is ALARM, tap **Unlock** first.
4. Tap **Home All**. The state shows HOME while the machine moves to its limit switches, then returns to IDLE.




Figure 2: Control > Actions

Important

The machine moves on its own while homing. Stand clear, keep a hand near the E-stop, and make sure nothing is in the way. If homing fails with an alarm, see the alarm table in section 3.4.

1.7 Moving the cutter: Jog and Dial

There are two ways to move the cutter by hand. Both are on the **Control** tab.

Jog: step buttons

1. Open **Control > Jog**.
2. Pick a **step size** from the column on the left (X/Y) or right (Z). 100 mm moves a long way; 0.1 mm is for fine adjustment.
3. Tap an arrow. The cutter moves by exactly one step. The corner arrows move X and Y together.
4. The **S:** and **F:** figures in the middle show the current step and feed rate. Use the **-1000 / -100 / +100 / +1000** buttons to change the feed.
5. Tap **STOP** to cancel a move that is still in progress.




Figure 3: Control > Jog

Dial: handwheel-style jogging

The **Dial** page has one dial for each axis (X, Y and Z, plus A if your machine has a rotary axis). Put a finger on a dial and turn it:

- **Clockwise** moves the axis in the **plus** direction; **anticlockwise** moves it in the **minus** direction.
- Every notch you turn (15 degrees) moves the axis by one step. Turn faster to move further.
- **Tap the centre** of a dial to change its step size (the choices come from Settings > Jog).
- While you turn, the figure under the dial shows how far you have moved. **STOP** cancels any move still queued.




Figure 4: Control > Dial

Tip

Use the Jog page to get close to the start point with big steps, then switch to a dial with a small step (0.1 mm or 1 mm) for the final adjustment.

1.8 Setting zero (where your job starts)

Your job file measures everything from a zero point. Before each job you tell the machine where that point is on your material. The zero is set for **X and Y** (usually a corner or the centre of the work) and for **Z** (usually the top surface of the material, or the spoilboard, depending on how your CAM file was set up). **Check how your file was prepared – the zero in the tablet must match the zero in your CAM software.**

By hand

1. Jog the cutter to the XY point that is your job's zero (for example the front-left corner of the material).
2. On **Control > Actions**, tap **Zero X** and **Zero Y** (or **Zero All** to include Z).
3. Jog the cutter down until it just touches the Z reference (for example the top of the material, or a sheet of paper that just drags). Tap **Zero Z**.
4. Check the **WPos** values on the Status tab: the axes you zeroed should read 0.000.

If zero will not set

The tablet will not set zero while the machine is in ALARM, still moving from a jog, or paused. A message tells you which; press **Unlock**, wait for the move to finish, or press **Resume**, then try again.

With the probe

The **Probe** page does the touching for you.

- **Z Probe** lowers the cutter onto the Z plate and sets Z zero. Set the plate on the material under the cutter and attach the probe clip to the cutter first.
- **XYZ Probe** uses the probe block to find the top and two sides of the block and sets X, Y and Z zero. Enter the cutter diameter in **Tool Dia** first.
- **Parameters** opens the probe settings (plate and block sizes and probe speeds). The factory values are a 15 mm Z plate and a 9 mm tall probe block; change them only if your probe is different.
- The **Probe result** box shows progress and any error.




Figure 5: Control > Probe

Important

Before probing, check the probe lead is connected and the clip is touching the cutter (not the plate). The machine moves automatically and slowly during probing; keep your hand near the E-stop.

1.9 Spindle Mode and Laser Mode

If your machine has both a spindle and a laser, the tablet needs to know which one the job is for. Use the two buttons at the top of the **Status** tab. The selected mode is solid; the other is an outline. The buttons are hidden while a job is running.




Figure 6: Laser Mode selected

Each tool has a **tool number**: normally **T0 for the spindle** and **T1 for the laser**. Before a job starts, the tablet reads the file and checks its tool numbers against the mode you have selected. If they do not match it stops and tells you, which prevents (for example) a spindle job being run in laser mode.

Changing the tool numbers

Open **Settings > General**. Under **MODE** there is a **Spindle** and a **Laser** row. Tap **-** or **+** to choose **Auto** (the tablet reads the number from the machine's configuration) or a fixed tool number from T0 to T99. The change applies straight away. If both are set to the same number, both rows turn amber and read "clash" – change one of them.




Figure 7: Settings > General

Note

Simple Mode (also under MODE) adds a guided **Carve** tab and hides Status, Macros and Terminal for operators who only need to run jobs. This manual describes the standard screens; Simple Mode is switched on and off with the same switch.

1.10 Getting job files onto the machine

Job files are made in your CAM software and saved as G-code (.nc or .gcode). Make sure the file was made with the correct post-processor for your machine. A spindle job should use tool **T0** (or no tool number); a laser job should use **T1**.

Option A: SD card

Copy the file onto the machine controller's SD card on your computer, put the card back in the controller, and open the **Files** tab. Choose **FluidNC SD** in the list at the top left, then tap **Refresh**. Use a card of 32 GB or less, formatted FAT32.

Option B: WiFi from your computer

1. Connect your computer to the **BLUECARVE** WiFi network (password **bluecarve**).
2. Open a web browser and go to the tablet's address (normally **http://192.168.0.2**; the exact address is on **Settings > Machine**).
3. Drag your file onto the page, or click to choose it. A progress bar shows the upload.

- On the tablet, open **Files** and tap **Refresh**. The new file appears in the list.




Figure 8: The Files tab. Delete (red), Preview (blue eye) and Play (green).

1.11 Previewing a file

Before running a new file, look at it. On the **Files** tab tap the blue **eye** next to the file. The **Preview** tab opens and draws the toolpath. Check that the shape and size look right.




Figure 9: The Preview tab

Large files take a few seconds to load; the page shows progress. If the file is very long the preview may show only the first part and the information line says so. This does not affect the job itself.

1.12 Other settings

Page	What you can change
General	Folders on top in the file list, A-axis (rotary) on/off, rotate the display 180 degrees, Simple Mode, and the Spindle and Laser tool numbers.
Backup	Export the tablet's settings to its SD card, or clear all settings.
Power	Screen dimming and sleep times.
Jog	Default jog steps and feed rates for each axis, and the step lists shown on the Jog and Dial pages.
Probe	Probe plate and block sizes and probe speeds.
WCS	Names and locks for the stored zero points (G54 to G59).
Machine	A summary read from the controller: axes, travel, spindle and laser, plus software versions and the tablet's web address.




Figure 10: Settings > Jog

2 Your first carve

This section takes you through a complete job from switching on to finished part. First comes the overview, so you can see the whole flow; then each step is explained.

2.1 Overview: the workflow at a glance

#	Where	What you do	You will know it worked when
1	Machine + tablet	Switch on the machine, then the tablet. Wait for the connection.	The bottom bar shows green IDLE and BLUECARVE .
2	Control > Actions	Home All (clear the bed first).	The state goes HOME, then back to IDLE.
3	On the machine	Fit the cutter, clamp the material, check clearances.	The material cannot move and nothing is in the cutter's way.
4	Status	Choose Spindle Mode (or Laser Mode).	The correct mode button is solid.
5	Files + Preview	Get the file on the machine, then preview it.	The preview shape and size are what you expect.
6	Control > Jog / Dial	Move the cutter to the start point of the job.	The cutter is exactly over your chosen X/Y zero.
7	Control > Actions	Set X and Y zero .	WPos X and Y read 0.000.
8	Control > Probe or Actions	Set Z zero (probe or by hand).	WPos Z reads 0.000 at your Z reference.
9	Files	Do the final checks, then tap Play .	The tablet checks the tool numbers and the Status tab shows RUN.
10	Status	Watch the carve. Pause, adjust or stop if needed.	The state returns to IDLE when the job is finished.
11	On the machine	Remove the part and clean up.	The machine is idle and the bed is clear.

Tip

The first time, run a short test file on scrap material with the cutter well above the work (for example with Z zero set 20 mm higher than normal) so you can watch the machine move without cutting.

2.2 Step 1: Power on and check the connection

1. Switch on the machine, then power the tablet.
2. Wait until the bottom bar shows **IDLE** in green.
3. If it shows **ALARM**, tap **Clear Alarm** (or **Control > Actions > Unlock**). If it still shows OFFLINE after about 30 seconds, go to section 3.2.

2.3 Step 2: Home the machine

Clear the bed, then go to **Control > Actions** and tap **Home All** (see section 1.6). Wait until the state returns to IDLE.

2.4 Step 3: Prepare the machine

- Fit the correct cutter and tighten the collet properly.
- Clamp the material securely. Keep clamps well away from the toolpath.
- Check that the toolpath fits on the material and inside the machine's travel.
- Turn on dust extraction.

2.5 Step 4: Choose the mode

On the **Status** tab tap **Spindle Mode** (for a router or plasma job) or **Laser Mode**. The selected button turns solid. The tablet sends the change to the machine; wait a moment until the button stops looking faded.

2.6 Step 5: Choose and preview your file

1. Open the **Files** tab. Choose **FluidNC SD** and tap **Refresh** if you have just added a file.
2. Tap the **eye** next to your file. The **Preview** tab opens and draws the job.
3. Check the size shown under the picture. If it is wrong, the file was probably made with the wrong units or size – fix it in your CAM software before going on.

2.7 Step 6: Move to the start point

Use **Control > Jog** to bring the cutter over the point that will be your job's X/Y zero. Use big steps to get close, then the **Dial** page with a 0.1 mm or 1 mm step for the last adjustment.

Important

Raise the cutter well above the material before moving across it. Use **Z+** on the Jog page.

2.8 Step 7: Set X and Y zero

On **Control > Actions** tap **Zero X** and **Zero Y**. On the Status tab, the work position X and Y now read 0.000.

2.9 Step 8: Set Z zero

With the probe: place the Z plate under the cutter, attach the clip, open **Control > Probe** and tap **Z Probe**.
By hand: lower the cutter slowly until it just touches your Z reference and tap **Zero Z**. Then raise the cutter a few millimetres.

Check **WPos Z** on the Status tab, and that the Preview's Z range makes sense for your job (for example, cut depths below zero).

2.10 Step 9: Final checks and Play

Before you press Play, run through this checklist:

✓	Check
☐	Machine homed; state is IDLE .
☐	Material clamped; clamps clear of the toolpath.
☐	Correct cutter fitted; dust extraction on.
☐	Correct mode selected (Spindle or Laser).
☐	X, Y and Z zero set; the cutter is above the material.

✓	Check
☐	Preview checked; the job fits the material.
☐	You are standing next to the machine with the E-stop in reach.

Then open the **Files** tab and tap the green **Play** button next to your file (or tap **Run** on the Preview tab). The tablet briefly shows “Checking job tool numbers...”, then starts the job and switches to the Status tab.




Figure 11: The tablet stops a job if its tool number does not match the selected mode

If you see the **Tool / mode mismatch** message, the job has **not** started. Either switch mode on the Status tab, or fix the file’s tool number in your CAM software, then press Play again.

2.11 Step 10: While the machine carves

The Status tab shows the job progress, the live positions and the speed. While a job runs the **Spindle/Laser** buttons are replaced by two buttons:

- **Pause** holds the machine; the state shows HOLD. The button changes to **Resume** – tap it to carry on.
- **STOP** ends the job. The tablet brings the machine to a halt and clears the alarm that a stop leaves behind, so you can jog or run another file straight away. For an emergency, use the machine’s **E-stop**.

To adjust speed while the job runs, open **Control > Overrides**. **Feed** changes how fast the machine moves, **Rapid** changes the speed of non-cutting moves, and **Spindle** changes the spindle speed. 100% is the speed in the file. The tablet will not raise the spindle override if that would take the spindle above its maximum speed.



Figure 12: Control > Overrides

2.12 Step 11: Finish up

1. When the state returns to **IDLE**, the job is done and the spindle has stopped.
2. Raise the cutter with **Z+** (or **Home Z**), then remove the part and clean the machine.
3. To carve another copy, set zero again only if you moved the material. To carve a different file, go back to Step 5.

2.13 Doing the same with Simple Mode

With **Simple Mode** switched on, the **Carve** tab guides you through the same job one screen at a time: choose a file, fit the cutter, set X/Y zero, set Z zero, confirm, then start. The safety checks, tool check and STOP behave the same way. Switch Simple Mode on or off in **Settings > General**.

3 Troubleshooting

Start with section 3.1. If your problem involves an alarm message, see 3.4. The tablet shows alarms and errors in plain English, so read the message first – it usually says what to do.

3.1 First things to try

1. **Read the message** on the screen (and tap **Alarms** on the Status tab to see recent alarms and errors).
2. If the machine is in alarm, fix the cause, then tap **Clear Alarm** or **Control > Actions > Unlock**.
3. If the tablet is acting strangely, **switch the tablet off and on again** (power lead out and back in).
4. If the machine does not answer at all, **switch the machine off and on again**, wait for the tablet to show IDLE, then home.
5. Make sure the **machine's own power is on**. The controller needs its power supply as well as USB.

3.2 Connection problems

Problem	What to check
The bar shows OFFLINE and does not connect	Is the machine switched on (its own power, not just USB)? Wait about 30 seconds after power-on. Restart the tablet. Make sure the tablet is within a few metres of the machine's controller.
It connects, then drops out	Move the tablet closer to the controller. Metal enclosures and cabinets block WiFi. Check that no other computer is trying to take over the connection to the machine.
A Disconnected or Connection failed pop-up appears	Tap the connect/restart button on the pop-up. If it keeps failing, restart the machine, then the tablet.
The WiFi name or password was changed on the controller	The tablet is set for BLUECARVE / bluecarve . If the controller was set up with different details, contact support.
The upload web page will not open on the computer	Join the BLUECARVE WiFi first. Use the address on Settings > Machine and type it with http:// , not https. Use Chrome or Edge.

3.3 Common problems

Problem	What to do
Jog buttons or dials do nothing	Check the state. In ALARM the machine will not move: clear the alarm first. If the state is HOLD, press Resume. If a previous move is still running, tap STOP on the Jog page.
The machine moves the wrong way	On the Dial page, clockwise is plus and anticlockwise is minus. If the machine moves opposite to the arrows on the Jog page, contact support (the axis direction is a machine setting).
Zero will not set: "Machine in ALARM", "Still moving" or "Machine paused"	Press Unlock , wait for the movement to finish, or press Resume , then tap the zero button again.
Zero not set pop-up	The controller refused the command. The pop-up gives the reason; fix it and try again. Restart the machine if it keeps happening.

Problem	What to do
Probing fails or the probe does not trigger	Check the probe lead is plugged in and the clip is on the cutter. Make sure the clip is not touching the plate before you start, and start close enough to the plate. See alarms 4 and 5 in section 3.4.
Tool / mode mismatch – the job will not start	The file asks for a different tool from the selected mode. Switch mode on the Status tab, or re-post the file from your CAM software with the correct tool number (T0 for spindle, T1 for laser).
Tool check unavailable	The tablet could not read the file to check it (for example the SD card was busy). Wait a moment and try again, or choose Run anyway only if you are sure the mode is right.
Controller busy	A probe routine or mode change is still running. Wait until it finishes.
Mode change failed	The machine did not accept the tool change. Make sure it is idle and not in alarm, then try again.
Spindle limit – the spindle override will not go up	Increasing the speed by 10% would exceed the spindle's maximum RPM, so the tablet blocked it. Lower the speed in the file if you need more room.
The Files list is empty or says the file system is not accessible	Check the SD card is fully inserted in the controller and the machine power is on. Use a FAT32 card of 32 GB or less. Tap Refresh . If it still fails, power the machine off and on with the card inserted.
A new file does not appear in Files	Tap Refresh . Check that you chose FluidNC SD at the top left, and that the file name ends in .nc or .gcode.
Preview is blank or slow	Large files can take several seconds. If the information line says the preview is truncated, only the first part is drawn; the job is unaffected. Tap the refresh button on the Preview tab to try again.
The touch screen does not respond or touches land in the wrong place	Switch the tablet off and on. Check the screen is clean and dry and that no case or screen protector is pressing on it. If it persists, contact support.
The screen is upside down	Settings > General > Rotate 180° , then Save Settings and restart the tablet.
The Spindle and Laser rows in Settings are amber and say "clash"	Both are set to the same tool number. Change one of them (usually Spindle = T0, Laser = T1).
The job stops by itself with ALARM	Read the alarm message (see section 3.4). Common causes are a limit switch hit, the E-stop pressed, or a motor driver fault.

3.4 Alarm messages

When the machine stops with an alarm, a red **ALARM** box appears with an explanation and a **Clear Alarm** button. Recent alarms are also listed under **Alarms** on the Status tab.




Figure 13: An alarm pop-up

No.	Alarm	What it means and what to do
1	Hard limit	A limit switch was hit while moving. Machine position is lost. Check for a crash or a false trigger, then re-home.
2	Soft limit	A move would go past the machine's travel. Check the job and your work zero fit inside the bed, and home the machine so positions are correct.
3	Reset while moving	Stop or reset was pressed during motion. Position may be lost, so re-home before continuing.
4	Probe already triggered	The probe read as touching before probing started. Make sure the clip or magnet is not touching the plate and the probe lead is not shorted.
5	Probe did not touch	The probe travelled the full distance without contact. Start closer to the plate, check the clip is on the bit, or increase the seek distance.
6	Homing reset	The homing cycle was stopped before it finished. Home again.
7	Homing: door open	The safety door was opened during homing. Close it and home again.
8	Homing: pull-off failed	A limit switch was still triggered after backing off. Check the switch and wiring.
9	Homing: switch not found	A limit switch was not reached within the axis travel. Check the switch, its connector and cable, and that the axis moves freely.
10	Spindle control	The spindle or VFD did not respond as expected. Check VFD power and wiring.
11	Control input active	Usually the E-stop is pressed or a motor driver reports a fault. Release the E-stop, check the drivers, then clear the alarm.
12	Homing: switch already on	A limit switch was already triggered when homing started. Jog the axis off the switch, then home.
13	Hard stop	Motion was stopped instantly. Position may be lost, so re-home.
14	Not homed	This machine must be homed before moving. Run Home All.
15	Startup / config problem	The controller found a problem during start-up. Contact support.

3.5 Error messages from the controller

These appear in the Alarms list or in a pop-up. The most common ones are:

No.	Message	What to do
9	Locked by alarm or jog	G-code is blocked while the machine is in ALARM or jogging. Clear the alarm or wait for the jog to finish.
15	Jog past travel	The jog would go past the machine limits and was ignored. Jog in the other direction, or re-home.
20	Unsupported G-code	The job contains a command the controller does not support. Re-post the file with the correct post-processor.
22	Feed rate not set	A cutting move has no F feed rate. Check the post-processor, or add an F value.
60–67	SD card errors	The card could not be mounted, read or opened, or is busy. Re-seat the card, make sure the machine power is on, and do not remove the card while a job is running.
65	File not found	The file is no longer on the card. Refresh the Files list.
152	Config invalid	The controller's configuration file has a problem. Contact support.

3.6 Updating the software

Updates for the tablet are published on the TouchBLUE Updater web page: <https://touchblue.pages.dev> (it shows the latest version and has this manual to download). **This updates the tablet only.** Do not try to change the machine controller's software yourself; if you think the controller needs an update, contact support.

1. Use a computer with **Google Chrome or Microsoft Edge** and a good-quality USB data cable (not a charge-only cable). Plug the cable directly into the computer, not a USB hub.
2. Open the installer page and click **Install TouchBLUE**, then choose the tablet's port from the list.
3. Follow the prompts. **Do not unplug the cable until it says it has finished** – it can take up to about 3 minutes.
4. When the update finishes, switch the device off and on again.

If the update fails

If you see “**Invalid head of packet (0xff)**”, the USB connection dropped out. Try a different cable and a different USB port on the computer, avoid hubs, and try again. It is safe to repeat the update.

Updating the tablet does not erase its settings.

3.7 Getting help

If you cannot solve a problem, contact BlueCarve support and have these details ready:

- the **TouchBLUE version** and **FluidNC version** (shown on **Settings > Machine**);
- the exact **message or alarm** shown, and what you were doing when it appeared;
- a photo of the screen, and of the machine if it is a hardware problem.

BlueCarve support	
Business	Maltek Pty Ltd (BlueCarve CNC), Laverton North VIC 3026
Phone	0448 431 833
Email	adam@endmill.com.au
Machine model and serial number	

4 The web page: files, Tools and this manual

The tablet has its own small web page, reachable from a computer on the **BLUECARVE** WiFi at **http://192.168.0.2** (the exact address is on **Settings > Machine**). Nothing needs installing and no internet is needed. It has three parts, shown across the top:

Page	What it does
Send a file	Drop a G-code file from your computer; it goes straight to the machine's SD card (section 1.10, Option B).
Tools	Surface (spoilboard surfacing), DXF → G-code (profile cuts with holding tabs), V-carve , Nest / array , Laser image , 3D relief , Viewer & checker and Feeds & speeds . Each shows the result first, then saves the job to the SD card, starts it or downloads it. The buttons under the Tools menu save and open projects .
Manual	This manual, stored on the tablet.

The top right of every page shows the machine state as the tablet sees it (IDLE, RUN, ALARM, OFFLINE ...). The Tools pages remember what you typed last time on that computer.

Starting a job from the web page

Save to SD only stores the file; you then run it from the tablet's **Files** tab as usual. **Save & Run** stores it and starts it straight away after you confirm – the tablet must show IDLE, and the same safety rules as any job apply (section 2, step 9). The job then shows on the tablet's Status tab, where **Pause** and **STOP** work as normal.

4.1 Surfacing the spoilboard

Surfacing skims the top of the spoilboard flat and parallel to the cutter's travel. Do it when a new spoilboard is fitted, when it is scarred from earlier jobs, or whenever parts come out with uneven depth. You need a large flat-bottomed cutter (a surfacing or "fly" cutter, typically 22–50 mm).

Before you start

1. Fit the surfacing cutter and remove clamps, fences and anything else from the area to be surfaced.
2. Home the machine (section 1.6).
3. Jog the cutter to the **front-left corner** of the area you want to surface and set **X and Y zero** there (section 1.8).
4. Lower the cutter until it just touches the **highest point** of the board (paper test or Z probe) and set **Z zero**. The surfacing cut goes **below** this by the depth you choose.

Making the job

Open **Tools > Surface** on the web page and fill in the boxes. Sensible starting values are already there.

Setting	Meaning
Width (X), Length (Y)	Size of the area, measured from the X0 Y0 corner you set.
Tool diameter	The surfacing cutter's diameter, in mm.
Stepover	How far each row moves across, as a percentage of the diameter. 40–50% gives a smooth finish; smaller is smoother and slower.
Depth per pass, Passes	How deep each pass cuts and how many passes. 0.5 mm × 1 is a light skim; use 2–3 passes to take more off a badly scarred board.

Setting	Meaning
Feed, Plunge, Spindle	Cutting speed, downward speed and spindle rpm. Use your cutter maker's figures for MDF.
Safe Z	Height the cutter lifts to for rapid moves.
Cut along X or Y	Direction of the rows. Choose the long side.
Zigzag	On: cuts in both directions (fastest). Off: cuts one way only and rapids back, for a more even finish.
Return to X0 Y0	Goes back to the start corner when finished.

The **Result** box shows the file name, number of rows, total depth and a time estimate, and the picture shows the area and the rows. Then tap **Save to SD** (run it later from the Files tab), **Save & Run** (start now) or **Download** (keep the .nc file on the computer).

Important

The cutter is half outside the board at the edges of the area – keep hands, clamps and the dust shoe clear. Stand by the machine with the E-stop in reach for the whole job.

4.2 DXF → G-code

This turns a 2D DXF drawing (from CAD, Inkscape, LightBurn, Fusion 360, AutoCAD and most others – save as **ASCII DXF**, **R12** or **2000**) into a profile-cutting job: the cutter follows each line, circle, arc or curve in the drawing. It is meant for parts – outlines, holes, slots, signs. For lettering and logos use **V-carve**, and for 3D carving use **3D relief**.




Figure 14: DXF → G-code with holding tabs (orange marks)

Steps

1. Open **Tools > DXF → G-code** and click **Open DXF**. Choose the drawing on your computer. The page lists how many shapes it found and the drawing's units; the toolpath appears on the right.
2. If the drawing has layers, tap a layer name to leave it out (for example a dimensions layer).

3. Choose where the drawing sits on the machine under **Origin: Bottom-left → X0 Y0** (most common), **Centre → X0 Y0**, or **As drawn** (the drawing's own coordinates).
4. Check **Units**. Most drawings say which they use; if the size shown looks 25 times too big or small, switch between mm and inch.
5. Choose the **Mode: Spindle** cuts to a depth in passes; **Laser** traces the lines with the laser at a set power.
6. Choose the **Cut side** and enter the **Tool diameter** (see below), then the depth, speeds and safe height.
7. Check the picture: the dotted outline is your drawing, the solid line is where the **centre of the cutter** will travel, and the white dots show where each shape starts. The box under it gives the finished size.
8. Tap **Save to SD**, **Save & Run** or **Download**, as for surfacing.

Cut side and tool diameter

A cutter has width, so the machine must run beside the line, not on it, for the part to come out the right size. The page offsets the path by half the tool diameter:

Cut side	Use it for
On line	The cutter centre follows the drawing exactly. Engraving, V-carving a centre line, or when your CAD already drew the cutter path.
Outside	Cutting a part out: the cutter runs outside the shape, so the part is the drawn size.
Inside	Cutting a hole or window: the cutter runs inside the shape, so the hole is the drawn size.
Auto	Outer shapes are cut outside and any shape drawn inside another (holes) is cut inside . Right for most parts with holes in them.

Shapes too small for the cutter (for example a 4 mm hole with a 6 mm cutter) are skipped and the page says so. Small shapes are cut before big ones so holes are finished before the part comes free. Offset cuts run in the climb direction (outside clockwise, inside anticlockwise). Open lines that do not form a closed shape are always cut on the line.

Final pass offset

For a cleaner edge, enter a **Final pass offset** such as 0.3 mm. Every roughing pass then leaves that much extra material, and one more pass at full depth removes it in a single light cut. Leave it at 0 to switch this off.

Depth and passes

Total depth is how far below Z zero to cut – set Z zero on the **top of the material** and make the total depth the material thickness plus about 0.2–0.5 mm to cut into the spoilboard. **Depth per pass** sets how much each pass takes; the page works out the number of passes.

Holding tabs

Without tabs, a part comes free on the last pass and can be thrown by the cutter. **Holding tabs** leave small bridges of material that hold the part in the sheet; cut them afterwards with a knife or saw and sand them flush.

1. Set **Cut side** to Outside, Inside or Auto (tabs are only used on closed shapes cut beside the line).
2. Turn **Tab**s on. Enter **Tab**s per shape (for example 4), or set it to 0 and enter a spacing (for example one every 150 mm).

3. Enter the **Tab width** (the material left along the cut, for example 5 mm) and the **Tab height** (how thick the bridge is, for example 2 mm). Leave **Ramped edges** on so the cutter rolls over each tab instead of stepping up and down.
4. Check the picture: orange squares mark the tabs. The page keeps them away from sharp corners.

Passes above the tab top cut straight through; only the deeper passes lift over each tab. Shapes too small for two tabs are cut without tabs, and the result box says so – hold those with tape or screws. Tabs are also left on the final pass.

Holding the part

Tabs hold the part in the sheet, not the sheet to the bed: clamp or screw the sheet down well outside the toolpath. Keep the E-stop in reach.

Checking before cutting

Save the job to the SD card, then open it with the blue eye on the tablet's **Files** tab: the **Preview** tab shows exactly what the machine will do, with the size in millimetres. Run the first part in scrap or with Z zero set well above the material.

What the DXF may contain

Lines, polylines (with rounded corners), circles, arcs, ellipses, splines and blocks (grouped shapes, including nested, scaled and rotated ones) are all used. Text, dimensions, hatching and images are ignored – convert text to outlines in your drawing program if you want it cut. Lines whose ends touch are joined into one shape automatically.

4.3 V-carve

V-carving cuts lettering and logos with a V-shaped bit. The cutter goes deeper where the shape is wide and shallower where it is narrow, so letters get sharp corners and clean walls. It uses the DXF opened in **DXF → G-code** (with the same units, layers and origin), or open one here with **Open DXF**. Only closed shapes are carved, so convert text to outlines (curves) in your drawing program first.




Figure 15: V-carve: depth map of a two-tool carving

1. Open **Tools > V-carve** and check the drawing name at the top.
2. Enter the V-bit **Angle** (60°, 90° ...) and **Tip diameter** (0 for a pointed bit).
3. Enter a **Max depth** (for example 3 mm). Wide areas that would go deeper are cleared flat at this depth. 0 means no limit.
4. Choose the **Output: V-bit only • 1 file**, or **Two tools • 2 files** (see below).
5. Check the picture. **Depth map** shows the finished carving shaded; **3D** and **Top** show the toolpath.
6. Tap **Save to SD**, **Save & Run** or **Download**.

Output	What happens
V-bit only • 1 file	One tool, one file. The V-bit cuts the walls and also clears any wide flat floors at max depth. Simple, but wide floors are slow and show small ridges; a smaller Flat stepover makes them smoother.
Two tools • 2 files	File 1 uses a flat end mill to clear the wide floors quickly. File 2 uses the V-bit for the walls and the corners the end mill can't reach. Run file 1 first, then fit the V-bit, set Z zero on the same surface again, and run file 2.

Two files

Save to SD puts both files on the card. **Save & Run** starts file 1; when it finishes, change the tool, re-zero Z and start file 2 from the tablet's **Files** tab. The file names start with **_1_** and **_2_** so the order is clear.

4.4 Nest / array

Nesting fits many copies of your parts onto one sheet, so you cut a full sheet in one job. The parts come from the DXF opened in **DXF → G-code**: each outer shape is one part, with its holes and any lines inside it.




Figure 16: Nest / array: parts nested on a sheet

1. Open **Tools > Nest / array**. Each part is listed with its size; enter how many **copies** of each you want.

2. Choose **Nest on sheet** and enter the sheet size, the margin around the edge and the **gap between parts**. Make the gap at least the cutter diameter (plus a little), or the cutter will cut into the next part. **Allow rotation** lets parts turn to fit better.
3. Or choose **Grid array** to repeat the whole drawing in columns and rows with a set gap.
4. Tap **Arrange** and check the picture and the result (how many fit, and how much of the sheet is used).
5. Tap **Use layout**. **DXF → G-code** and **V-carve** now work on the whole sheet, with the cut side, tabs and depths you set there. **Clear layout** goes back to the single drawing.

If not every part fits, the page says how many were left out: use a bigger sheet, a smaller gap, or cut a second sheet.

4.5 Laser image

This engraves a photo or logo with the laser, line by line, with the power following how dark each point is. Open a PNG or JPG with **Open image**.

Setting	What it does
Width	The engraved width in mm; the height keeps the picture's shape. X0 Y0 is the bottom-left corner.
Line interval	Distance between lines. 0.1–0.2 mm is typical; smaller is finer but slower.
Mode	Greyscale varies the power; Dither uses dots, good for photos on wood; Black/white cuts everything darker than the Threshold , best for logos.
Brightness, Contrast, Gamma	Adjust the picture before engraving. Invert engraves the light areas instead.
Max / Min power (S)	The laser power for black and for the lightest engraved grey. Max is usually your laser's full power (the controller's S range, often 1000).
Overscan	Extra travel at each end of a line so the laser is moving at full speed while it burns. Leave a few mm.

The picture shows the engraving as it will burn, and the result gives the size and an estimated time. Focus the laser on the material and use the laser's safety glasses and extraction.

4.6 3D relief

A 3D relief turns a greyscale picture (a heightmap) into a carving: **white is the top surface and black is the deepest point**. Heightmaps come from relief software, 3D programs or online libraries.




Figure 17: 3D relief: finishing path with a tapered ball nose

1. Open **Tools > 3D relief** and click **Open image**.
2. Enter the **Width** and the **Depth** of the carving. **Smoothing** softens a noisy picture; **Resolution** sets how fine the model is (higher is finer and slower to calculate).
3. Choose the **Passes** (see below) and the finishing tool: **Ball nose** (enter its diameter) or **Tapered ball nose** (enter the tip diameter, the taper in degrees per side and the shank diameter).
4. Enter the **Stepover**. For a ball nose 8–12% of the diameter gives a smooth finish; for a fine tapered tip 25–40% of the tip is typical.
5. Tap **Make G-code**. Reliefs take a few seconds to calculate. Check the picture (**Depth map** shows the model) and the result: file names, time and the scallop height (the small ridges between passes).
6. Tap **Save to SD**, **Save & Run** or **Download**.

Passes	What happens
Rough + finish · 2 files	File 1: a flat end mill removes most of the material in steps, leaving a small allowance (for example 0.5 mm). File 2: the ball nose or tapered ball nose follows the surface. Run file 1, change the tool, set Z zero on the top of the stock again, run file 2. Fastest for deep reliefs.
Finishing only · 1 file	One tool, no tool change. The finishing tool cuts down in depth passes (Stepdown , for example 2 mm) and the last pass follows the surface. Good for shallow reliefs and fine detail.

Fine tools

A tapered ball nose has a very small tip. Keep the stepdown small (the page warns above twice the tip diameter) and the feed moderate. Finishing jobs can take hours – check the time estimate before you start.

4.7 Viewer & checker

This shows any G-code file in 3D and checks it before it goes near the machine: open a file from the computer with **Open G-code**, or tap **Check** under any tool to check what it just made. Drag to turn the

view, shift-drag or right-drag to move it, and scroll to zoom. Cuts are coloured by depth and rapid moves are dashed; **Simulate progress** shows how far the job has got at any point.




Figure 18: Viewer & checker: a file with problems found

Choose your machine model and stock thickness. The checker then warns about:

- rapid (G0) moves below the material surface, which would crash the cutter;
- cutting with the spindle off, or before a feed rate is set;
- a job bigger than the machine's travel, or cutting deep into the spoilboard;
- codes FluidNC does not support (such as cutter compensation G41/G42) and tool changes (M6).

It also works out the **run time** (allowing for the machine's acceleration) and a **job cost**: enter your machine rate per hour, setup time, material and tool wear, the quantity and your markup to get a price.

4.8 Feeds & speeds

This gives starting feeds and speeds for solid-carbide router bits. Choose the material and bit type, enter the diameter, flutes and spindle speed; the page shows the RPM, feed, plunge rate, depth per pass and chip load, limited to what the machine can do (it lowers the RPM if the feed would be faster than the machine allows). The table underneath shows the same bit in other materials. **Use in DXF → G-code** copies the values into the DXF tool.

TouchBLUE Send a file **Tools** Manual machine 192.168.0.1 **IDLE**

Feeds & speeds

JOB

Material: **MDF / particleboard**

Bit type: **Upcut**

Diameter: **6** mm

Flutes: **2**

RPM: **18000**

MACHINE

Max feed: **8000** mm/min

Max Z feed: **500** mm/min

Min RPM: **6000**

Max RPM: **24000**

STARTING VALUES

RPM: **11700**

Feed: **8000 mm/min**

Plunge: **500 mm/min**

Stepdown: **6 mm**

Stepper: **40%**

Chip load: **0.3412 mm/tooth**

Light stepover: chip-thinning compensation x1.02

Feed capped at machine max 8000 mm/min — RPM lowered to 11723 to keep the chip load

→ Use in DXF → G-code

SAME BIT, OTHER MATERIALS

Material	RPM	Feed	Plunge	Stepdown
Softwood (pine)	16800	8000	500	6
Hardwood (oak, ash)	18000	7830	500	3
Plywood	15100	8000	500	4.5
MDF / particleboard	11700	8000	500	6
Acrylic (cast)	18000	6190	500	3
HDPE / soft plastics	18000	7000	500	6
Aluminium composite (ACM)	18000	5210	500	6
Aluminium	18000	1740	500	1.5

Figure 19: Feeds & speeds

Fine-tuning

These are starting points. Make a test cut: a steady hum and clean chips are right; squealing or dust means the feed is too low or the RPM too high; a labouring spindle means too deep or too fast.

4.9 Saving projects and settings

The buttons at the bottom of the Tools menu save your work as a file on the computer, so you can open it again later or on another computer.

Button	What it does
Save project	Saves every setting in every tool plus the DXF drawing, the nested layout, the laser and relief pictures and the file in the checker. Opening it puts everything back as it was, on the tool you were using.
Save settings	Saves only your machine, tool and cutting settings (no drawings or pictures). Use it to keep your workshop defaults, or to set up another computer the same way.
Open project	Opens a saved project or settings file (.touchblue).

Files are saved to the computer's **Downloads** folder (or the browser asks where to save them, if it is set to). The page also remembers your last settings in this browser, but a saved file is the safe copy.